


Parking Veghel and on the road

Parking in Veghel, Doornhoek.




There are designated spaces for single trucks and uncoupled trailers or combinations. For liquid bulk, always park so that two chassis can fit in one space. Cars should be parked in the designated spaces behind the guardrail.

Parking in Europoort

Dintelweg 87, Haven (Port) 6211

There is very limited parking space here. It is not permitted to park outside the designated spaces, in the street, or to uncouple trailers/chassis on the street. Overnight parking is also not permitted.

Parking in Kranenburg, Im Hammereisen



Parking in Erp

Other than the car park behind the workshop, parking is not allowed in Erp.

Parking the truck along the way

When planning your drive, ensure you have an idea of the best place to park. While parking, several points are important. Before leaving, run through the mandatory checklist.

- Leave your truck unattended as rarely as possible.
- Try to park along a busy road, preferably in a busy and/or guarded car park and in a well-lit, visible spot.
- Park your truck where you can keep a good view on the vehicle when you are not in the immediate vicinity.
- Park your truck in a way the minimises the risk of damage. For example, not at the front but a bit further back so a colleague is unlikely to hit your cabin.
- Lock your truck properly, switch on the alarm system and check that all windows and doors are closed properly.
- Always take your valuables, documents, and passes with you.
- Upon returning to your truck, and in the morning before departure, check for any signs of break-ins or damage that was not there previously. Check seals, twist locks and fifth wheel plate.
- Look around carefully for any suspicious people or things; people who have no business being in a car park or display suspicious behaviour.